

Carsoft[®]™

Ultimate Home Software



*FOR MERCEDES-, BMW-, SPRINTER- AND
MINI VEHICLES*

*ON-BOARD-DIAGNOSTICS
FOR MS-WIN ME/2000/XP/VISTA/7™ OPERATING SYSTEM*

© CARSOFT INTERNATIONAL - BELGIUM & DIRK SCEVENELS

Carsoft^{®TM} - License

This is a legal agreement between you, the end user, and *Carsoft International*, a corporation after Belgium law.

By opening the sealed software packages, and/or using the software, you are agreeing to be bound by the terms of this agreement. If you do not agree to the terms of this agreement, promptly return the unopened disk packages and the accompanying items (including written materials and binders or other containers) to the place you obtained them for a full refund.

Carsoft International notifies you that with today's technical standards, it is not possible to produce software without making any mistakes.

The licensor and/or supplier do not make any guarantees for the accuracy of the support text or documents and are not liable or responsible for any damage resulting from the use of **Carsoft^{®TM}** products, even if the user was not notified about mistakes in the software. The licensor and/or *Carsoft International* have reserved its rights to make changes any time, to take out or to add anything in the handbook or the software.

Carsoft International grants you the right to use the enclosed software on a single computer. You cannot make a copy or install the software in any network or use the software on different computers at the same time. The software is owned by *Carsoft International*, and is protected by international copyright- and intellectual property laws, international treaty provisions, and all other national laws.

The software has technical protection against copying.

Any technical endorsement, especially from other programs, will result in non-function of the software. In this case, the user has no right to replace his software. The user has to install the software a hard drive. He can only start his software from the hard drive after installation. It is not legal to copy any enclosed material such as the manual or other material which was delivered with the software.

You may not rent or lease the software, but you may transfer the software and accompanying written materials on a permanent basis only if the licensor and/or *Carsoft International* give the written permission to do so, provided you retain no copies and the recipient agrees to the terms of the agreement. You may not reverse, engineer, decompile or disassemble the software. If the software is an update or has been updated, any transfer must include the most recent update and all prior versions.

For rights to receive updates of the software and the possibility to get technical assistance, you must send a record card to Carsoft International - Belgium.

In case there is no record card enclosed, or if you can't start the software with the enclosed disk, please contact your supplier or the place from where you purchased the software.

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any purpose, without the express written permission of the licensor and/or *Carsoft International* - Belgium.

© Copyright by Carsoft International & Dirk Scevenels - All rights reserved.

- **MERCEDES (Sprinter)** is a registered trademark of Daimler-Chrysler AG Stuttgart.
- **BMW (Mini)** is a registered trademark of Bayerische Motorwerke AG München.
- **Microsoft** and **Windows** are registered trademarks of Microsoft Corporation.
- **IBM** is a registered trademark of Industry Business Corporation.
- **Carsoft^{®TM}** is a registered trademark of *Carsoft International*

Information in this document is subject to change without notice. The licensor and/or *Carsoft International* have reserved its rights to make any time changes, to take out or to add anything in the manual or the software.

The software and the documentation are specific from country to country!

INDEX

- ▶ 1. Welcome
- ▶ 2. Carsoft^{®™} Ultimate Home hardware specifications
- ▶ 3. Carsoft^{®™} Ultimate Home Installation
 - How to make a Vista administrator account
 - Software Installation
- ▶ 4. Carsoft^{®™} Ultimate Home hardware connection
 - Cable connection to the Computer
 - Cable connection to the Vehicle
 - Security Dongle connection
- ▶ 5. Carsoft^{®™} Ultimate Home software setup
 - COM PORT Setup
- ▶ 6. Carsoft^{®™} Ultimate Home Mercedes Start
- ▶ 7. Carsoft^{®™} Ultimate Home Sprinter Start
- ▶ 8. Carsoft^{®™} Ultimate Home BMW/Mini Start
- ▶ APPENDIX A. No Communication
- ▶ APPENDIX B. For More Info
- ▶ APPENDIX C.
- ▶ APPENDIX D.

1. Welcome

Welcome to **Carsoft**®™ the first Diagnostic Software for Mercedes- and SPRINTER Vehicles for Microsoft Windows operating systems.

You have chosen to invest in an item of modern technology, which you will soon find to be an important workshop tool. To ensure your satisfaction with this product, our **Carsoft**®™ team will bring you updates whenever the technology requires. In these updates, we will provide new functions and new possibilities for Diagnostics. With these updates your **Carsoft**®™ diagnostic software will always be on the forefront of technology.

Through the worldwide spreading of **Carsoft**®™ we improve our experience and know-how. However, we need you -our partners- to improve **Carsoft**®™ to make your daily work even more efficient. Please feel free to address any criticisms or suggestions for improvements to your supplier.

With the contact numbers you can obtain advice on software or operating questions as well as receive news of future updates to the software. We are, however, unable to give advice on repairs to the car itself.

The **Carsoft**®™ soft- and hardware is a tool which is developed to operate for years. **Carsoft**®™ gets continuously updated, in order to provide a competent service for your customer. The actual software is a basic program which will accompany you for a long time.

We welcome you as a partner on our team!

Dirk Scevenels

Carsoft®™ team

For **INFO** please contact:

Carsoft International


Grand Route 111C
B 4367, CRISNEE
Belgium

Tel. : +32/19.54.54.29

Fax : +32/19.54.54.30

EMAIL : info@carsoftsales.com

2. Carsoft [®]™ Ultimate Home hardware specifications



Carsoft [®]™ is developed for use on IBM - compatible computers under Microsoft Windows operating system. The software is NOT compatible with other operating systems

Minimum System Requirements:

- ⇒ Pentium [®] III 500 MHz
- ⇒ 128 MB RAM
- ⇒ 500 MB Hard Disk Space
- ⇒ 1280x768 Screen Resolutions
- ⇒ CD-ROM or DVD-ROM Drive
- ⇒ Serial Port to connect vehicle interface cable
- ⇒ USB 1.1 or 2.0 Port to connect security dongle
- ⇒ Microsoft Windows ME-, 2000-, XP-, Vista-, or 7
- ⇒ A printer is necessary to use the printing functions

These above specifications can be found in the hardware manuals of the manufacturer of your computer.



3. Carsoft[®]™ Ultimate Home Installation



IMPORTANT:

DO NOT INSTALL ANY HARDWARE COMPONENTS (USB SECURITY DONGLE OR USB CABLE) UNTIL THE **CARSOFT[®]™** SOFTWARE INSTALLATION HAS BEEN COMPLETED!

Info: If you are using WINDOWS **VISTA**, you must be logged in as **administrator**.

See next page for more info.

How to make a Vista administrator account

With full administrative access rights (full control)...

* Windows Vista Business, Enterprise or Ultimate:

1. Click **Start**, type **secpol.msc** in the search box, then press **Enter**
2. From the list on the left, choose **Local Policies**, then **Security Options**
3. Set **Accounts: Administrator account status** to **Enabled**
4. Set **User Account Control: Admin Approval Mode for the Built-in Administrator account** to **Disabled**


* Windows Vista Home Basic or Home Premium:

1. Click **Start**, type **cmd** in the search box, right click on the program **cmd.exe** and select **Run as Administrator**
2. In the command prompt window, type **net users Administrator /active:yes** then press **Enter**, you should receive a confirmation saying; *The command completed successfully*
3. Click **Start**, type **regedit** in the search box, then press **Enter**
4. Navigate to the section:
[HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\Policies\System]
 - o Double click **FilterAdministratorToken** and set it to **0**
5. Next, **logoff** and you will see that a new **Administrator** account will be available. Login to this new Administrator account

You're now logged in to Windows Vista with full administrative rights. You will not receive any security prompts like before and you should have complete administrative rights to your machine.


SOFTWARE INSTALLATION

- Insert the [Carsoft Ultimate Home CD](#) into the CD ROM drive
(Do NOT CONNECT the dongle at this moment)
- Wait until the [Welcome](#) screen appears, and click **NEXT**




(If the Auto run feature is not switched on, double click the Setup Icon on the CD)


- Wait until the [License Agreement](#) screen appears, then mark **“I accept the terms in the license agreement”**, and click **NEXT**




- Wait until the [Customer Information](#) screen appears and verify **“User Name”** and **“Organization”**, and click **NEXT**




- Wait until the [Destination Folder](#) screen appears, and click **NEXT**



- Wait until the, [Ready to Install the Program](#), screen appears, and click **INSTALL**



- Wait until the [Install Shield Wizard Completed](#) screen appears, then click **FINISH**



- Start the Carsoft Ultimate Pro application; by double click the Launch Carsoft.exe icon on your desktop.



- When you start the program for the first time you will be asked to install the Dongle drivers.

- Now connect the dongle to the USB port of your computer.

After this, the Dongle will be recognized by the windows operating system, and the drivers will be installed automatically. (This can take a few minutes, when it is completed, the windows operating system will inform you that the new dongle can be used)

4. Carsoft[®]™ Ultimate Home hardware connection

A) The serial connector at Carsoft Main Box will be connected with a serial cable to a free serial port from your computer

B) The connector at the other side from the Main Box will be connected to the vehicle with an adapter cable.

**1) BMW or MB Vehicles equipped with an OBD2 Socket.
>>> MAIN box with OBD Adapter.**

**2) BMW Vehicles equipped with 20 PIN Socket.
>>> Main box with 20 PIN Adapter**

**3) MB Vehicles equipped with 38 PIN Socket.
>>> Main box with 38 PIN Adapter**

C) Security Dongle Connection



Security Dongle



Free USB Port

When you connect the dongle for the first time to a free USB Port the following message will appear:



Wait a few seconds, until the next message appears:



>>> Now the dongle is ready to be used <<<<

Remark:

This procedure has to be repeated on all the USB ports where you want to use the dongle on.

5. Carsoft[®]™ Ultimate Home software setup

COM Port Setup


Click the ['Launch Carsoft'](#) icon to start the software



Click the ['Setup'](#) button at the left bottom.



Select the appropriate COM port number (See page 13 and 14 for more info)




INFO : COM Port Number Verification

Checking Serial COM Port Number.

This is a guide detailing how to check the settings of the Serial COM Port.

(Although the images are taken from a Windows '98, the procedure is nearly identical under Windows 2000, Windows ME and Windows XP as well.)

From the Windows **“Start”** button, select **Settings- Control Panel** to bring up the Windows Control Panel.




From the Windows Control Panel select and click on the **“System”** icon. The following System Properties screen should be displayed on the PC ...



Select the **“Device Manager”** tab, and use the “View devices by type” option. Scroll down the page until Ports (COM & LPT) is shown then click on the “+” symbol to show the entries in this category.

Look for an entry **“Serial Port”** with a COM Port number following it, click on it to select it, then click on the “Properties” button at the page to see more details of the device. In the illustration below the Virtual **COM Port is set to COM3** – this may be different depending on which devices have been installed prior to plugging in the serial device.

The General page of the properties screen shows a few details about the device and confirms that the device is working properly (as far as Windows is concerned).




6. Carsoft[®]™ Ultimate Home Mercedes Benz Start

Click the ['Launch Carsoft'](#) Icon to start the software.



Click the ['Mercedes Ultimate'](#) button to start the 'Mercedes Benz' software.




Here you make the selection between ['Passenger Vehicles'](#) and ['Off Road Vehicles'](#)



After this you have to select the car type. (For Example [E Class](#))



After the car type selection you select the car model (For Example [W210 Diesel](#))



Now you can make a selection between:

A: Total Diagnosis: Click [‘Total Diagnosis’](#)

B: Single Diagnosis: Click [‘Single Diagnosis’](#)

A: Total Diagnosis:

The 'Total Diagnosis' makes a quick overview from the control units actually build in into the car. It gives also an overview of the status from each control unit.

To start the Total Diagnosis: Click the 'START' button.



Possibility 1 : Status : OK



No actual or stored errors stored in the control unit.

Possibility 2: Status: Read the error memory!



Errors stored in the error memory.

The error memory can be read by performing a single diagnosis from the control unit. To go to the single diagnosis, click the button at to the left-hand side.

Possibility 3: Status: Module does not respond



Verify if the control unit is build in into the car. Otherwise verify the cable connection to the computer and to the car. Also verify the battery voltage of the car.

B: Single Diagnosis:

The 'Single Diagnosis' gives you detailed information about the control units and the status of the control unit.

To go to 'Single Diagnosis': Click the ['Single Diagnosis'](#) button.

| Vehicle | Connector | Control Unit | Engine Type | Model |
|---------|-----------|--------------|-------------|-----------------------|
| W124 | 38 | DIGITAL | DIESEL | |
| W210 | 38 | DIGITAL | DIESEL | TILL 03/97 |
| W210 | 38 | DIGITAL | DIESEL | FROM 03/97 TILL 02/01 |
| W210 | 38 | DIGITAL | DIESEL | FROM 02/01 |
| W211 | OBD | DIGITAL | DIESEL | TILL 05/06 |
| W211 | OBD | DIGITAL | DIESEL | FROM 06/06 |
| W124 | 38 | DIGITAL | PETROL | |
| W210 | 38 | DIGITAL | PETROL | TILL 03/97 |
| W210 | 38 | DIGITAL | PETROL | FROM 03/97 TILL 02/01 |
| W210 | 38 | DIGITAL | PETROL | FROM 02/01 |
| W211 | OBD | DIGITAL | PETROL | TILL 05/06 |
| W211 | OBD | DIGITAL | PETROL | FROM 06/06 |

Carsoft Ultimate Home




The control units are divided in the following menus:

1. ► Driveline
2. ► Chassis Systems
3. ► Body
4. ► Information and Communications
5. ► Air-conditioning

In these menus, depending to the selected car, car-type and control unit, multiple functions are possible:

Example [‘Drive Line’](#)



Example [‘CDI Control Unit’](#)



1. ► Read/Erase Fault Codes
2. ► Live Data
3. ► Component
4. ► Component Tests
5. ► Component Activations
6. ► Control Unit Coding
7. ► Component Coding
8. ► Adaptation Functions
9. ► Etc. ...

Single Diagnosis Test Results:



Tip: All control units have stored errors. Some control units have actual errors.

Possibility 1 ► Status: OK



No actual or stored errors stored in the specific control unit.

Possibility 2 ► Status: Error




Errors stored in the error memory.

Possibility 3 ► Status: No Communication




Verify if the specific control unit is build in into the car. Otherwise verify the cable connection to the computer and to the car. Also verify the battery power of the vehicle.

► Click the **PRINT** button here, you have the opportunity to print the diagnosis result.



► Click the **SAVE** button here, you have the opportunity to save the diagnosis result.



► Click the '[CIS](#)' button to start the Carsoft information system.



In order to continue you have first have to make the vehicle selection:

> Step 1: Select the Car (Vehicle Type)

(Models are listed in numerical order)

> Step 2: Select The Engine No.

> Step 3: Select The Error code

(If there are multiple error codes, each one can be selected, but they must be selected on at a time.)



After the selection the CIS buttons will be enabled.

(Wiring Diagram/Component Information/Error Code Explanation)

1) Wiring Diagram

Depending to the vehicle and system selected, several choices may be available.

For some systems, due to the complexity, there may be two or more diagrams available.



2) Component Information

The component information info provides the following information on a component:

- Position
- Task
- Function / Design

The screenshot shows a software interface titled "Component Explanation" for a "Hot film MAF sensor" (P0100) on a "CDI : C200 CDI - 611". The page is divided into sections: "Position", "Task", "Design", and "Function".

- Position:** Info available in Component Location.
- Task:** Detection of air mass supply to the engine and intake air temperature.
- Design:** The air mass supplied to the engine influences the temperature at the hot film sensor by flowing through the air mass sensor in the air intake passage. At same time integrated NTC resistor detects the intake air temperature.
- Function:** It maintains the difference of temperature by 160 degree higher from intake air temperature by using an adjustable voltage level to control the temperature of the heating resistor. The temperature of the heating resistor is detected by the sensor resistor. If a temperature change occurs as a result of the increased or reduced air flow, the electronics alters the voltage at the heating resistor until the temperature difference is reached again. This voltage is used by the engine.

On the right side, there is a 3D diagram of the sensor with labels: "Housing", "NTC Resistor", and "Protective grille". Navigation arrows are located below the diagram.


At the bottom of the interface, there are buttons for "Back", "Main", "Help", "Location", and "Exit". A status bar at the very bottom shows the date "5/8/2007" and time "4:17 PM".

If you click on the '[Location](#)' button the component location page will be opened.

The screenshot shows a software interface titled "Component Location" for a "Hot film MAF sensor" (P0100) on a "CDI : E220 CDI - 646". The page displays two images: a technical drawing of the engine compartment on the left and a photograph of the engine on the right. Both images have a red box labeled "B2/S" indicating the sensor's location. Below the images, a red box contains the text "MAF - Hot film MAF sensor".

At the bottom of the interface, there are buttons for "Back", "Main", "Help", and "Exit". A status bar at the very bottom shows the date "6/10/2007" and time "11:32 AM".

3) Error Code Explanation



CDI : E220 CDI - 646 P0100 Error Code Explanation

Hot Film Mass Air Flow Sensor...

Test to be performed :

1. Check, is there any Air Leakage

1. Check, is there any Air Leakage

← Fault Characteristics →

Substitute value formation, no exhaust gas recirculation.

← Test to be performed →

1. Check, is there any Air Leakage
2. Check Cables, connectors between CDI control module and Hot Film MAF Sensor

1. Check the Supply Signal
 - >> Upper limit value : 4.93 V
 - >> Lower limit value : 0.25 V
2. Check the Supply Voltage
 - >> Upper limit value : 5.1 V
 - >> Lower limit value : 4.6 V
3. Fault Possibility

Diagram labels: B2/5, 9/5, 9/1, RH, RL, RS

Legend:
9/1 Hot Film Sensor
9/5 Electronic housing
RH Heating resistor
RS Sensor Resistor

>> Hot Film Mass Air Flow Sensor...

Back Main Help Exit

6/10/2007 11:43 AM

Types of information on the error code explanation page:

- Error Code
- Explanation of when fault occurs (Failure mode, Conditions, Etc. ...)
- Test Programs
- Test values and parameters
- Test Procedure
- Pictures or diagrams may also be available depending on error codes.

Special Functions.


Click the **'Exit'** button to exit the CIS part.




Click the **'Back'** button to return to the CDI page.



Here you can enter the available functions for the selected control unit, can be entered by clicking them. >>> Example: **'Live Data'**




Click the ['Back'](#) button to return to the CDI page.



Here you can enter the available functions for the selected control unit, can be entered by clicking them. >>> Example ['Tests'](#)



Here you can select the required test.



Used Buttons



Back ► To return to the previous screen



Main ► To return to the Main Menu



Start ► To start the total diagnosis



Help ► Help file



Scan ► To start scanning the error memory



Erase Codes ► To erase the error codes



No Com. ► No Communication with the vehicle



Save ► To save the data to disk



Print ► To print the data on paper



Exit ► To exit the program



Manual ► To open the manual

Used Abbreviations

4MATIC - Automatically controlled four-wheel drive
AAC(KLA) - Automatic air conditioning
AB - Airbag
AB - Airbag Control Unit
ABC - Active body control
ABS - ABS Control Unit
ABS - Antilock brake system
ACS(KLS) - Air conditioning seat
ACSR(AKSE) - Automatic child seat recognition
ADM(ASA) - Automatic dimming mirror
ADS - Adaptive damping system
AGW - Audio Gateway Control Unit
AHV - Trailer hitch
AIRCO - Air conditioning Control Unit
AIRMatic - Airmatic System Control Unit
AKR - Semi Automatic Gear Box Control Unit W168
ALR(AFE) - Automatic child seat recognition
APS - Auto pilot system
ARMIN - Airbag with integrated emergency call system
AS(ATS) - Antenna systems
ASD - Automatic locking differential
ASR - Acceleration slip regulation
AT(AG) - Automatic transmission
ATA(EDW) - Anti-theft alarm
BA(RFH) - Backup assist
BAS - BAS Control Unit
BAS - Brake assist
BCAPC(ALDA) - Barometric pressure/charge air pressure compensation
BDC(UT) - Bottom dead center
BM(GM) - Base module
CA(SHI) - Closing assist
CAAC - Convenience automatic air conditioning
CAN - Controller Area Network (databus)
CC(TPM) - Cruise control
CCM(SKF) - Multifunction control module
CDC(CDW) - CD changer
CDI - Common Rail Diesel Engine Control Unit
CDI - Common Rail Diesel Injection (CDI)
CF(KFB) - Convenience feature
CIS - Carsoft Information System
CL(ZV) - Central locking
CNS - Communication and navigation system
COMAND - Cockpit Management and Data System
Command - Command
CRA(KW) - Crank angle
CST(CV) - Cabriolet soft top
CTEL(TEL) - Cellular telephone
CTU(ZAE) - Central triggering unit(airbag)
D2B - D2 bzs
DAS(FBS) - Drive authorization system
DBE - Overhead Control Panel Control Unit
DCM(TSG) - Door control module
DFI(EVE) - Diesel injection system (electronic distributor fuel injection)
DMNL(DH) - Diagnosis Manual
DSV(ASF) - Drive authorization system shut-off valve
DTR - Distronic
DTR - Distronic(distance cruise control)
DWR(AWR) - Distance warning radar
EA(EFP) - Electronic accelerator
EAS(EVL) - Electrically adjustable steering column

EBR(MSR) - Engine braking regulation
 E-Call - Emergency call system
 ECI - Electronic controlled ignition
 EDC - Electronic diesel control

 EDR - Electronic diesel regulation
 EDS - Electronic diesel system
 EDW - Anti Theft Alarm Control Unit
 EGR(ARF) - Exhaust gas recirculation
 EGS - Electronic Gearbox Control Unit
 EHD - Electronic high pressure diesel injection system
 EIS(EZS) - Electronic ignition switch control module
 EL(ABL) - Exterior lights
 ELC(ENR) - Electronic level control
 EPC - Electronic power control
 ERE - Diesel Engine Control Unit
 ESA(ESV) - Electric seat adjustment
 ESCM(MAS) - Engine systems control module
 ESM - Electronic selector lever module
 ESP - Electronic stability program
 ESP - ESP Control Unit
 ESVVL - Electronic Seat Adjustment Control Unit
 ESVVR - Electronic Seat Adjustment Control Unit
 ETC(EGS) - Electronic transmission control
 ETR(GUS) - Emergency tensioning retractor
 ETS - Electronic traction system
 EVE - Diesel Engine Control Unit
 EWM - Electronic slever Control Unit
 EZS - Electronic Ignition System
 FAN - Fanfare horns system
 FBS - Drive Authorization Signal Control Unit
 FFS(RBA) - Frame-floor system
 FG - Function subgroup
 GPS - Global positioning system
 HB(ZH) - Heater booster
 HCS(SRA) - Headlamp cleaning system
 HEAT(HAU) - Automatic heater
 HFM - Petrol Engine Control Unit
 HFM-SFI - Fuel injection and ignition system hot film engine management
 HFS(FSA) - Hands-free system
 HHT - Hand-held Tester
 HRA(LWR) - Headlamp range adjustment
 HRS(SIF) - Heated rear seats
 HS(SIH) - Heated seats
 IC(KI) - Instrument cluster
 ICS - Information and communication system
 IFI(ERE) - Diesel injection system(electronic inline fuel system)
 IMM(WFS) - Immobilizer
 IR - Infrared
 ISC(ELR) - Electronic idle speed control
 ISC(LLR) - Idle speed control
 KI - Instrument Cluster Control Unit
 KSS(AKR) - Knock sensor system
 LCP(UBF) - Lower control panel
 LHS(LL) - Left hand steering
 LH-SFI - LH-SFI fuel injection and ignition system
 LOC(NV) - Low compression
 LR(LDH) - Lamella roof
 LS(LSA) - Loudspeaker system
 LWR - Headlight Range Adjustment Control Unit
 MCS(MKS) - Multicontour seat
 ME - Petrol Engine Control Unit
 ME-SFI - ME-SFI fuel injection and ignition system
 MKL - Multicontour backrest

MRA - Residual engine heat utilization
MRS - Multifunction restraint system
MS(IRS) - Interior motion sensor
MSC(ESL) - Mirror, steering column adjustment, heated mirrors
MT(MG) - Manual transmission
MVA(SRU) - Manifold vacuum assist
OBD - On-board diagnosis
OBF - Upper Control Panel Control Unit
OCP - Overhead control panel control module
OMS - Operating monitoring system
OSB(OSL) - Orthopaedic seat backrest
PE - Plan Electrics
PEC(PMS) - Fuel injection and ignition system(Pressurized engine control)
PISE(PLA) - Pneumatic idle speed increase
PL(SVS) - Power locking
PMP(PSV) - Partial intake manifold preheater
PMS - Petrol Engine Control Unit
PROX(ABW) - Distance Warner
PS(LS) - Power steering
PSE - Pneumatic Control Unit
PSE - Pneumatic system equipment
PTS - Parktronic system
PTS - Parktronic System Control Unit
PW(EFH) - Power windows
RAS(HAL) - Rear axle steering
RB(URB) - Roll bar
RB(URB) - Roll bar crash deployment
RCL(IFZ) - Remote central locking
RD - Radio
RDS - Radio data system
RFL(FFZ) - Radio frequency locking/electric central locking
RFL/RCL(FFZ/IFZ) - Radio frequency/remote central locking
RHR(KAF) - Retractable rear head restraints
RHS(RL) - Right hand steering
RST(RV) - Roadster soft top
RTC(HDFS) - Remote trunk lid closing
RTG(VHG) - Retractable trunk lid grip
RTR(HDF) - Remote trunk release
RUF - Catalytic converter retrofit version
RWD(HHS) - Rear window defroster
SA - Special equipment
SAM - Signal acquisition and actuation module
SAM - Signal Acquisition Module Control Unit
SAMH - Rear Signal Acquisition Module Control Unit
SAMV - Front Signal Acquisition Module Control Unit
SAMVL - Front Left Signal Acquisition Module Control
SAMVR - Front Right Signal Acquisition Module Control
SBC - Sensitive Brake Control Unit
SBC - Sensotronic Brake Control
SBE(GUB) - Seat belt extender
SBL - Seat ventilation
SCM - Steering column module
SEQ - Sequential automated manual transmission
SEQ(KSG) - Sequentronic manual transmission
SIH - Heated Seats Control Unit
SMS(RA) - Service microfiche system
SPS(PML) - Speed-sensitive power steering
SR(SHD) - Tilting/sliding roof
SRS - Supplemental restraint system
SSG - Sprintshift Control Unit
STH - Stationary heater
SVMCM(MSS) - Special vehicle multifunction control module
TAC(TAU) - Tempmatic air conditioning
TAL(HZS) - Trunk lid auxiliary lock

TC(TURBO) - Turbocharger
 TD - Speed signal (time division) DI(EZL)
 TDC(OT) - Top dead center
 TELE AID - Telematic alarm identification on demand(emergency call system)
 TN - Speed signal (EZL/AKR)
 TPC(RDK) - Tire pressure control
 TPM(RDU) - Tire pressure monitoring
 TRIP(RRE) - Trip computer
 TS(AS) - Towing sensor
 TSG - Door Control Unit
 TSGHL - Rear Left Door Control Unit
 TSGHR - Rear Right Door Control Unit
 TSGVL - Front Left Door Control Unit
 TSGVR - Front Right Door Control Unit
 TV - TV Tuner
 TWC(KAT) - Three-way catalytic converter
 UBF - Lower Control Panel Control Unit
 UHI - Telephone
 UPC - Upper control panel
 UVS - Roadster Roof Control Unit
 UVS(RVC) - Roll bar soft top control
 VCS(SBS) - Voice control system
 VD - Vario Roof Control Unit
 VR(VD) - Vario roof
 VSS(GES) - Vehicle speed signal
 ZAS - Cylinder shut-off
 ZGW - Central Gateway Control Unit
 (+) - Positive
 (-) - Negative
 15 - Switched ground behind battery, ignition / starter switch output
 15 DIA - Switched positive, diagnosis
 15 UG - Switched positive, infused
 15g - Switched positive, fused
 15R - Switched positive, in ignition position I' 2 and 3
 15X - Switched positive, in ignition position 2
 30 - Battery, input from battery positive, direct
 30Z - U battery circuit 30Z, infused
 31 - Return circuit to battery negative or ground, direct
 31b - Return circuit to battery negative or ground through switch or relay, switched negative
 49 - Turn signal pulse generator input
 49a - Turn signal' pulse generator output
 49aL - Left turn signal pulse generator output
 49aR - Right turn signal pulse generator output
 50 - Starter control (direct)
 53 - Wiper motor, input (+)
 53b - Wiper (shunt)
 54 - Stop lamp
 56 - Headlamp beam
 56a - Main beam and main beam indicator
 56b - Low beam
 58 - Limit, tail, license plate and instrument lamps
 58L - Left clearance, tail licence plate and instrument lights
 58R - Right clearance, tail licence plate and instrument lights
 58d - Variable instrument / switch lighting
 61 - Generator indicator
 85 - Switching relay, winding end negative or ground
 86 - Switching relay, winding start
 87 - Relay contact for NC contact and changeover contact, input
 87a - Relay contact for NC contact and changeover contact, first output (NC side)
 87b - Relay contact for NC contact and changeover contact, second output
 87ABS - Traction systems relay contact input
 87F - Fanfare horns relay contact input
 87KP - Fuel pump assembly relay contact input
 87LP - Air pump relay contact input

87M1 - Circuit 87M1 fused
 87M2 - Circuit 87M2 fused
 A88F+ - Passenger airbag+
 A88F- - Passenger airbag-
 A8FA+ - Driver airbag+
 A8FA- - Driver airbag-
 ABBF- - Front passenger airbag -
 ABBF+ - Front passenger airbag +
 ABFA- - Driver airbag -
 ABFA+ - Driver airbag +
 AKSE - Automatic child seat recognition
 Anten. - Antenna
 ASR-OFF - ASR-OFF switch
 AP - Output proportional
 AP EV1 - Output proportional injector 1
 AP EV2 - Output proportional injector 2
 AP EV3 - Output proportional injector 3
 AP EV3 - Output proportional injector 4
 AP MO+ - Output proportional motor+
 AP MO- - Output proportional motor-AP
 AP NWS - Output proportional camshaft sensor
 AP ULK+ - Output potentiometer recalculated air flap+
 AP ULK- - Output potentiometer recalculated air flap-
 AS - Output shift
 AS LSHK - O2 sensor heater, downstream TWC
 AS SLV - Output shift air pump switchover valve
 ASR OFF - ASR OFF switch
 Ay- - Lateral acceleration-
 Ay+ - Lateral acceleration+
 B33 On - ATA ON tilt sensor
 B33 Off - ATA OFF tilt sensor
 B33 Alarm - ATA ALARM tilt sensor
 B+ - Battery positive
 B- - Battery negative
 BBWL - Brake pad wear, front left
 BBWR - Brake pad wear, front right
 BF - Front passenger
 BL - Stop Lamp
 BLA - Stop light shutoff
 BS - Stop lamp switch
 CAN BUS(H) - CAN (high)
 CAN BUS(L) - CAN (low)
 CAN IH - CAN interior bus (high)
 CAN IL - CAN interior bus (low)
 CDW 30 - CD changer circuit 30
 CDW 31 - CD changer circuit 31
 CDW - CD changer control
 Crash Sig. - Crash Signal
 Crash-A - Crash Signal output
 D+ - Dynamo, positive
 D- - Dynamo, negative
 D28 IN - D2-BUS, input
 D28 OUT - D2-BUS, output
 DF - Dynamo field
 DF ST A - Speed frequency control module output
 DFVL - Speed sensor front left
 DFA-VL - Speed sensor output front left
 DFHA - Speed sensor rear axle
 DFHL - Speed sensor rear left axle
 DFHR - Speed sensor rear right axle
 DFVL - Speed sensor front left axle
 DFVR - Speed sensor front right axle
 DG - Pressure sensor
 DIA - Diagnosis

DRS - Yaw rate sensor
 EA - Input analogue
 EF - Input frequency
 E-AUS – Input signal -off
 E-KSK - Input-shift signal -shift contact control
 E-S+B - Input-shift signal -set / accelerate
 E-S-B - Input-shift signal -set / accelerate (decelerate)
 E-WA - Input-shift signal -resume
 F - Fanfare horns
 FA - Driver
 FSA+ - Hands free system+
 FSA- - Hands free system-
 GAL - Speed-dependend volume control
 GND - Ground
 GS - Emergency tensioning retractor
 GS8FA+ - Passenger emergency tensioning retractor, positive
 GS8FA- - Passenger emergency tensioning retractor, negative
 GSFA+ - Driver emergency tensioning retractor, positive
 GSFA- - Driver emergency tensioning retractor, negative
 (H) - High
 HAS - Hand brake, signal
 HHS - Rear window defroster
 HL AV - Rear left solenoid valve pressure reduction
 HL EV - Rear left solenoid valve pressure holding
 HR AV - Rear right solenoid valve pressure reduction
 HR EV - Rear right solenoid valve pressure holding
 Ke - License plate lamp
 KP - Fuel pump group
 (L) - Low
 LP - Air pump
 L/R - Left/right
 LS - Release switch
 LWS - Steering angle sensor
 M1 - Ground 1
 M2 - Ground 2
 MBBVVL - Ground, left front brake pad wear
 MBBVVR - Ground, right front brake pad wear
 MDFHL - Ground, left rear speed sensor
 MDFHR - Ground, right rear speed sensor
 MDFVL - Ground, left front speed sensor
 MDFVR - Ground, right front speed sensor
 Mikr.+ - Microphone positive
 Mikr.- - Microphone negative
 ML - Ground (power ground°
 MMV - Solenoid valve
 MRA - Engine relay actuation
 MRU - Engine relay voltage
 MUTE - Muting
 MV+ - Solenoid valve positive
 N.C. - Not connected
 Ne - Fog lamp
 NSL - Rear fog lamp
 Not Used - Not connected
 P - Parking lamp
 R1-LED - LED display, rear window defroster switch
 R1S - Control signal, rear window defroster switch
 Rue. - Backup lamp
 S1 - Brake assist release switch, switch position 1
 S2 - Brake assist release switch, switch position 2
 SB - Accelerate (cruise control)
 SBS - Side airbag sensor
 Sig. Diag. - Diagnose Signal
 SN1 - Lock switch 1
 SN2 - Lock switch 2

SP1M - Specified value potentiometer 1 ground
SP1S - Specified value potentiometer 1 signal
SP2M - Specified value potentiometer 2 ground
SP2S - Specified value potentiometer 2 signal
STATUS - Speed sensor output, status
SV - Decelerate (cruise control)
TK - Door contact
UB - Voltage, operation
UG - Unfused
UMRFP - Return flow pump monitor
USP1 - Voltage supply specified value potentiometer 1
USP2 - Voltage supply specified value potentiometer 2
USV - Switchover solenoid valve
VL AV - Front left solenoid valve pressure reduction
VL EV - Front left solenoid valve pressure holding
VR AV - Front right solenoid valve pressure reduction
VR EV - Front right solenoid valve pressure holding
W/S - Program selection (winter/summer)
W0 - Selector lever position code 0
W1 - Selector lever position code 1
W2 - Selector lever position code 2
W3 - Selector lever position code 3

7. Carsoft [®]™ Ultimate Home Sprinter Start

Click the **'Launch Carsoft'** Icon to start the software.



Click the **'Sprinter Ultimate'** button to start the 'Sprinter software.



Then you have to make a selection between **Diesel** and **Petrol**



Now you can make a selection between:

A: Total Diagnosis : Click **Total Diagnosis**

B: Single Diagnosis : Click **Single Diagnosis**

A: Total Diagnosis:

The 'Total Diagnosis' makes a quick overview from the control units actually build in into the car. It gives also an overview of the status from each control unit.

To start the Total Diagnosis: Click the 'Start' button.



Possibility 1: Status : OK



No actual or stored errors stored in the control unit.

Possibility 2: Status: Read the error memory!



Errors stored in the error memory.
The error memory can be read by performing a single diagnosis from the control unit.
To go to the single diagnosis, click the button at to the left-hand side.

Possibility 3: Status: Module does not respond



Verify if the control unit is build in into the car. Otherwise verify the cable connection to the computer and to the car. Also verify the battery voltage of the car.

B: Single Diagnosis:

The 'Single Diagnosis' gives you detailed information about the control units and the status of the control unit.

To go to **Single Diagnosis**: Click the '[Single Diagnosis](#)' button.





The control units are divided in the following menus :

1. ► Driveline
2. ► Chassis Systems
3. ► Body
4. ► Information and Communications
5. ► Air-conditioning

In these menus, depending to the selected car, car-type and control unit, multiple functions are possible:

Example **Drive Line**



Example **CDI Control Unit**



1. ► Read/Erase Fault Codes
2. ► Live Data
3. ► Component
4. ► Component Tests
5. ► Component Activations
6. ► Control Unit Coding
7. ► Component Coding
8. ► Adaptation Functions
9. ► Etc. ...

Single Diagnosis Test Results:

The screenshot shows the 'Carsoft Ultimate Home' interface. On the left, a sidebar displays 'Status : ERROR' in a red box, followed by 'Module Info :'. Below this, fields for Part Number (646 153 56 91), Software Version (11/05), Hardware Version (43/02), Diagnosis Recognition (2/02), and Supplier (Bosch) are shown. The main window displays 'Carsoft MB Ultimate' and 'Date : 7/2/2008 1:39:11 PM'. It lists three error codes: P2242 (No or incorrect CAN message from Traction system hydraulic unit), P2208 (CAN communication with ESP/SPS/BAS control unit: Timeout), and P2333 (Vehicle speed cruise control: Wheel Speed). At the bottom, a toolbar contains icons for Back, Home, Print, Save, Scan, Erase Codes, CIS, F.E.D., No Com., Help, and Exit. The status bar at the very bottom shows the date, time, and file path: '7/2/2008 1:39 PM Passenger Vehicles\E Class\Single Diagnosis\Driveline\CDI Error Codes\'

Tip: All control units have stored errors. Some control units have actual errors.

Possibility 1 ► Status: OK

The screenshot shows a 'Status Report' window with a green bar containing the text 'OK'.

No actual or stored errors stored in the specific control unit.

Possibility 2 ► Status: Error

The screenshot shows a 'Status Report' window with a red bar containing the text 'Error'.


Errors stored in the error memory.

Possibility 3 ► Status: No Communication


The screenshot shows a 'Status Report' window with a yellow bar containing the text 'No Communication'.

Verify if the specific control unit is build in into the car. Otherwise verify the cable connection to the computer and to the car. Also verify the battery power of the vehicle.

► Click the **PRINT** button here, you have the opportunity to print the diagnosis result.



► Click the **SAVE** button here, you have the opportunity to save the diagnosis result.



► Click the **CIS** button to start the Carsoft information system.



In order to continue you have first have to make the vehicle selection:



- > Step 1: Select the Car (Vehicle Type)
(Models are listed in numerical order)
- > Step 2: Select The Engine No.
- > Step 3: Select The Error code
(If there are multiple error codes, each one can be selected, but they must be selected on at a time.)

After the selection the CIS buttons will be enabled.
(Wiring Diagram/Component Information/Error Code Explanation)

1) Wiring Diagram

Depending to the vehicle and system selected, several choices may be available.

For some systems, due to the complexity, there may be two or more diagrams available.



2) Component Information

The component information info provides the following information on a component:

- Position
- Task
- Function / Design

The screenshot shows a software interface for component information. At the top, there are three tabs: 'CDI: C200 CDI - 611', 'P0100', and 'Component Explanation'. The main content area is titled 'Hot film MAF sensor'. It contains sections for 'Position', 'Task', 'Design', and 'Function', each with a double-headed arrow icon. The 'Task' section describes the detection of air mass and temperature. The 'Design' section explains the sensor's operation. The 'Function' section details the temperature control mechanism. To the right, there is a 3D diagram of the sensor with labels for 'Housing', 'NTC Resistor', and 'Protective grille'. Below the diagram are navigation arrows. At the bottom, there is a 'Back' button, 'Info' and 'Exit' buttons, and a status bar showing the date and time: '11/10/2008 10:00 AM'.

If you click on the '[Location](#)' button the component location page will be opened.

The screenshot shows a software interface for component location. At the top, there are three tabs: 'CDI: E220 CDI - 646', 'P0100', and 'Component Location'. The main content area displays a photograph of an engine compartment with a red box highlighting the location of the MAF sensor, labeled 'B2/S'. Below the photograph, there is a red box with the text 'MAF - Hot film MAF sensor'. At the bottom, there is a 'Back' button, 'Info' and 'Exit' buttons, and a status bar showing the date and time: '11/10/2008 10:00 AM'.

3) Error Code Explanation

CDI : E220 CDI - 646 P0100 Error Code Explanation

Hot Film Mass Air Flow Sensor...

Test to be performed :

1. Check, is there any Air Leakage

1. Check, is there any Air Leakage

← Fault Characteristics →

Substitute value formation, no exhaust gas recirculation.

← Test to be performed →

1. Check, is there any Air Leakage
2. Check Cables, connectors between CDI control module and Hot Film MAF Sensor

1. Check the Supply Signal

- >> Upper limit value : 4.93 V
- >> Lower limit value : 0.25 V

2. Check the Supply Voltage

- >> Upper limit value : 5.1 V
- >> Lower limit value : 4.6 V

3. Fault Possibility

9/1 Hot Film Sensor
9/5 Electronic housing
RH Heating resistor
RS Sensor Resistor

>> Hot Film Mass Air Flow Sensor...

Back Info Exit

11/10/2008 10:00 AM

Types of information on the error code explanation page:

- Error Code
- Explanation of when fault occurs (Failure mode, Conditions, Etc. ...)
- Test Programs
- Test values and parameters
- Test Procedure
- Pictures or diagrams may also be available depending on error codes.

Click the **'Exit'** button to exit the CIS part.



Click the **'Back'** button to return to the CDI page.



Here you can enter the available functions for the selected control unit, can be entered by clicking them. >>> Example: **'Live Data'**




Click the **'Back'** button to return to the CDI page.



Here you can enter the available functions for the selected control unit, can be entered by clicking them. >>> Example **'Tests'**



Here you can select the required test.



Used Buttons



Back ► To return to the previous screen



Main ► To return to the Main Menu



Start ► To start the total diagnosis



Help ► Help file



Scan ► To start scanning the error memory



Erase Codes ► To erase the error codes



No Com. ► No Communication with the vehicle



Save ► To save the data to disk



Print ► To print the data on paper



Exit ► To exit the program



Manual ► To open the manual

Used Abbreviations

4MATIC - Automatically controlled four-wheel drive
AAC(KLA) - Automatic air conditioning
AB - Airbag
AB - Airbag Control Unit
ABC - Active body control
ABS - ABS Control Unit
ABS - Antilock brake system
ACS(KLS) - Air conditioning seat
ACSR(AKSE) - Automatic child seat recognition
ADM(ASA) - Automatic dimming mirror
ADS - Adaptive damping system
AGW - Audio Gateway Control Unit
AHV - Trailer hitch
AIRCO - Air conditioning Control Unit
AIRMatic - Airmatic System Control Unit
AKR - Semi Automatic Gear Box Control Unit W168
ALR(AFE) - Automatic child seat recognition
APS - Auto pilot system
ARMIN - Airbag with integrated emergency call system
AS(ATS) - Antenna systems
ASD - Automatic locking differential
ASR - Acceleration slip regulation
AT(AG) - Automatic transmission
ATA(EDW) - Anti-theft alarm
BA(RFH) - Backup assist
BAS - BAS Control Unit
BAS - Brake assist
BCAPC(ALDA) - Barometric pressure/charge air pressure compensation
BDC(UT) - Bottom dead center
BM(GM) - Base module
CA(SHI) - Closing assist
CAAC - Convenience automatic air conditioning
CAN - Controller Area Network (databus)
CC(TPM) - Cruise control
CCM(SKF) - Multifunction control module
CDC(CDW) - CD changer
CDI - Common Rail Diesel Engine Control Unit
CDI - Common Rail Diesel Injection (CDI)
CF(KFB) - Convenience feature
CIS - Carsoft Information System
CL(ZV) - Central locking
CNS - Communication and navigation system
COMAND - Cockpit Management and Data System
Command - Command
CRA(KW) - Crank angle
CST(CV) - Cabriolet soft top
CTEL(TEL) - Cellular telephone
CTU(ZAE) - Central triggering unit(airbag)
D2B - D2 bzs
DAS(FBS) - Drive authorization system
DBE - Overhead Control Panel Control Unit
DCM(TSG) - Door control module
DFI(EVE) - Diesel injection system (electronic distributor fuel injection)
DMNL(DH) - Diagnosis Manual
DSV(ASF) - Drive authorization system shut-off valve
DTR - Distronic
DTR - Distronic(distance cruise control)
DWR(AWR) - Distance warning radar
EA(EFP) - Electronic accelerator
EAS(EVL) - Electrically adjustable steering column

EBR(MSR) - Engine braking regulation
 E-Call - Emergency call system
 ECI - Electronic controlled ignition
 EDC - Electronic diesel control
 EDR - Electronic diesel regulation
 EDS - Electronic diesel system
 EDW - Anti Theft Alarm Control Unit
 EGR(ARF) - Exhaust gas recirculation
 EGS - Electronic Gearbox Control Unit
 EHD - Electronic high pressure diesel injection system
 EIS(EZS) - Electronic ignition switch control module
 EL(ABL) - Exterior lights
 ELC(ENR) - Electronic level control
 EPC - Electronic power control
 ERE - Diesel Engine Control Unit
 ESA(ESV) - Electric seat adjustment
 ESCM(MAS) - Engine systems control module
 ESM - Electronic selector lever module
 ESP - Electronic stability program
 ESP - ESP Control Unit
 ESVVL - Electronic Seat Adjustment Control Unit
 ESVVR - Electronic Seat Adjustment Control Unit
 ETC(EGS) - Electronic transmission control
 ETR(GUS) - Emergency tensioning retractor
 ETS - Electronic traction system
 EVE - Diesel Engine Control Unit
 EWM - Electronic slever Control Unit
 EZS - Electronic Ignition System
 FAN - Fanfare horns system
 FBS - Drive Authorization Signal Control Unit
 FFS(RBA) - Frame-floor system
 FG - Function subgroup
 GPS - Global positioning system
 HB(ZH) - Heater booster
 HCS(SRA) - Headlamp cleaning system
 HEAT(HAU) - Automatic heater
 HFM - Petrol Engine Control Unit
 HFM-SFI - Fuel injection and ignition system hot film engine management
 HFS(FSA) - Hands-free system
 HHT - Hand-held Tester
 HRA(LWR) - Headlamp range adjustment
 HRS(SIF) - Heated rear seats
 HS(SIH) - Heated seats
 IC(KI) - Instrument cluster
 ICS - Information and communication system
 IFI(ERE) - Diesel injection system(electronic inline fuel system)
 IMM(WFS) - Immobilizer
 IR - Infrared
 ISC(ELR) - Electronic idle speed control
 ISC(LLR) - Idle speed control
 KI - Instrument Cluster Control Unit
 KSS(AKR) - Knock sensor system
 LCP(UBF) - Lower control panel
 LHS(LL) - Left hand steering
 LH-SFI - LH-SFI fuel injection and ignition system
 LOC(NV) - Low compression
 LR(LDH) - Lamella roof
 LS(LSA) - Loudspeaker system
 LWR - Headlight Range Adjustment Control Unit
 MCS(MKS) - Multicontour seat
 ME - Petrol Engine Control Unit
 ME-SFI - ME-SFI fuel injection and ignition system
 MKL - Multicontour backrest
 MRA - Residual engine heat utilization

MRS - Multifunction restraint system
MS(IRS) - Interior motion sensor
MSC(ESL) - Mirror, steering column adjustment, heated mirrors
MT(MG) - Manual transmission
MVA(SRU) - Manifold vacuum assist
OBD - On-board diagnosis
OBF - Upper Control Panel Control Unit
OCP - Overhead control panel control module
OMS - Operating monitoring system
OSB(OSL) - Orthopaedic seat backrest
PE - Plan Electrics
PEC(PMS) - Fuel injection and ignition system(Pressurized engine control)
PISE(PLA) - Pneumatic idle speed increase
PL(SVS) - Power locking
PMP(PSV) - Partial intake manifold preheater
PMS - Petrol Engine Control Unit
PROX(ABW) - Distance Warner
PS(LS) - Power steering
PSE - Pneumatic Control Unit
PSE - Pneumatic system equipment
PTS - Parktronic system
PTS - Parktronic System Control Unit
PW(EFH) - Power windows
RAS(HAL) - Rear axle steering
RB(URB) - Roll bar
RB(URB) - Roll bar crash deployment
RCL(IFZ) - Remote central locking
RD - Radio
RDS - Radio data system
RFL(FFZ) - Radio frequency locking/electric central locking
RFL/RCL(FFZ/IFZ) - Radio frequency/remote central locking
RHR(KAF) - Retractable rear head restraints
RHS(RL) - Right hand steering
RST(RV) - Roadster soft top
RTC(HDFS) - Remote trunk lid closing
RTG(VHG) - Retractable trunk lid grip
RTR(HDF) - Remote trunk release
RUF - Catalytic converter retrofit version
RWD(HHS) - Rear window defroster
SA - Special equipment
SAM - Signal acquisition and actuation module
SAM - Signal Acquisition Module Control Unit
SAMH - Rear Signal Acquisition Module Control Unit
SAMV - Front Signal Acquisition Module Control Unit
SAMVL - Front Left Signal Acquisition Module Control
SAMVR - Front Right Signal Acquisition Module Control
SBC - Sensitive Brake Control Unit
SBC - Sensotronic Brake Control
SBE(GUB) - Seat belt extender
SBL - Seat ventilation
SCM - Steering column module
SEQ - Sequential automated manual transmission
SEQ(KSG) - Sequentronic manual transmission
SIH - Heated Seats Control Unit
SMS(RA) - Service microfiche system
SPS(PML) - Speed-sensitive power steering
SR(SHD) - Tilting/sliding roof
SRS - Supplemental restraint system
SSG - Sprintshift Control Unit
STH - Stationary heater
SVMCM(MSS) - Special vehicle multifunction control module
TAC(TAU) - Tempmatic air conditioning
TAL(HZS) - Trunk lid auxiliary lock
TC(TURBO) - Turbocharger

TD - Speed signal (time division) DI(EZL)
 TDC(OT) - Top dead center
 TELE AID - Telematic alarm identification on demand(emergency call system)
 TN - Speed signal (EZL/AKR)
 TPC(RDK) - Tire pressure control
 TPM(RDU) - Tire pressure monitoring
 TRIP(RRE) - Trip computer
 TS(AS) - Towing sensor
 TSG - Door Control Unit
 TSGHL - Rear Left Door Control Unit
 TSGHR - Rear Right Door Control Unit
 TSGVL - Front Left Door Control Unit
 TSGVR - Front Right Door Control Unit
 TV - TV Tuner
 TWC(KAT) - Three-way catalytic converter
 UBF - Lower Control Panel Control Unit
 UHI - Telephone
 UPC - Upper control panel
 UVS - Roadster Roof Control Unit
 UVS(RVC) - Roll bar soft top control
 VCS(SBS) - Voice control system
 VD - Vario Roof Control Unit
 VR(VD) - Vario roof
 VSS(GES) - Vehicle speed signal
 ZAS - Cylinder shut-off
 ZGW - Central Gateway Control Unit
 (+) - Positive
 (-) - Negative
 15 - Switched ground behind battery, ignition / starter switch output
 15 DIA - Switched positive, diagnosis
 15 UG - Switched positive, unfused
 15g - Switched positive, fused
 15R - Switched positive, in ignition position 1' 2 and 3
 15X - Switched positive, in ignition position 2
 30 - Battery, input from battery positive, direct
 30Z - U battery circuit 30Z, unfused
 31 - Return circuit to battery negative or ground, direct
 31b - Return circuit to battery negative or ground through switch or relay, switched negative
 49 - Turn signal pulse generator input
 49a - Turn signal' pulse generator output
 49aL - Left turn signal pulse generator output
 49aR - Right turn signal pulse generator output
 50 - Starter control (direct)
 53 - Wiper motor, input (+)
 53b - Wiper (shunt)
 54 - Stop lamp
 56 - Headlamp beam
 56a - Main beam and main beam indicator
 56b - Low beam
 58 - Limit, tail, license plate and instrument lamps
 58L - Left clearance, tail licence plate and instrument lights
 58R - Right clearance, tail licence plate and instrument lights
 58d - Variable instrument / switch lighting
 61 - Generator indicator
 85 - Switching relay, winding end negative or ground
 86 - Switching relay, winding start
 87 - Relay contact for NC contact and changeover contact, input
 87a - Relay contact for NC contact and changeover contact, first output (NC side)
 87b - Relay contact for NC contact and changeover contact, second output
 87ABS - Traction systems relay contact input
 87F - Fanfare horns relay contact input
 87KP - Fuel pump assembly relay contact input
 87LP - Air pump relay contact input
 87M1 - Circuit 87M1 fused

87M2 - Circuit 87M2 fused
 A88F+ - Passenger airbag+
 A88F- - Passenger airbag-
 A8FA+ - Driver airbag+
 A8FA- - Driver airbag-
 ABBF- - Front passenger airbag -
 ABBF+ - Front passenger airbag +
 ABFA- - Driver airbag -
 ABFA+ - Driver airbag +
 AKSE - Automatic child seat recognition
 Anten. - Antenna
 ASR-OFF - ASR-OFF switch
 AP - Output proportional
 AP EV1 - Output proportional injector 1
 AP EV2 - Output proportional injector 2
 AP EV3 - Output proportional injector 3
 AP EV3 - Output proportional injector 4
 AP MO+ - Output proportional motor+
 AP MO- - Output proportional motor-AP
 AP NWS - Output proportional camshaft sensor
 AP ULK+ - Output potentiometer recalculated air flap+
 AP ULK- - Output potentiometer recalculated air flap-
 AS - Output shift
 AS LSHK - O2 sensor heater, downstream TWC
 AS SLV - Output shift air pump switchover valve
 ASR OFF - ASR OFF switch
 Ay- - Lateral acceleration-
 Ay+ - Lateral acceleration+
 B33 On - ATA ON tilt sensor
 B33 Off - ATA OFF tilt sensor
 B33 Alarm - ATA ALARM tilt sensor
 B+ - Battery positive
 B- - Battery negative
 BBWL - Brake pad wear, front left
 BBWR - Brake pad wear, front right
 BF - Front passenger
 BL - Stop Lamp
 BLA - Stop light shutoff
 BS - Stop lamp switch
 CAN BUS(H) - CAN (high)
 CAN BUS(L) - CAN (low)
 CAN IH - CAN interior bus (high)
 CAN IL - CAN interior bus (low)
 CDW 30 - CD changer circuit 30
 CDW 31 - CD changer circuit 31
 CDW - CD changer control
 Crash Sig. - Crash Signal
 Crash-A - Crash Signal output
 D+ - Dynamo, positive
 D- - Dynamo, negative
 D28 IN - D2-BUS, input
 D28 OUT - D2-BUS, output
 DF - Dynamo field
 DF ST A - Speed frequency control module output
 DFVL - Speed sensor front left
 DFA-VL - Speed sensor output front left
 DFHA - Speed sensor rear axle
 DFHL - Speed sensor rear left axle
 DFHR - Speed sensor rear right axle
 DFVL - Speed sensor front left axle
 DFVR - Speed sensor front right axle
 DG - Pressure sensor
 DIA - Diagnosis
 DRS - Yaw rate sensor

EA - Input analogue
 EF - Input frequency
 E-AUS – Input signal -off
 E-KSK - Input-shift signal -shift contact control
 E-S+B - Input-shift signal -set / accelerate
 E-S-B - Input-shift signal -set / accelerate (decelerate)
 E-WA - Input-shift signal -resume
 F - Fanfare horns
 FA - Driver
 FSA+ - Hands free system+
 FSA- - Hands free system-
 GAL - Speed-depended volume control
 GND - Ground
 GS - Emergency tensioning retractor
 GS8FA+ - Passenger emergency tensioning retractor, positive
 GS8FA- - Passenger emergency tensioning retractor, negative
 GSFA+ - Driver emergency tensioning retractor, positive
 GSFA- - Driver emergency tensioning retractor, negative
 (H) - High
 HAS - Hand brake, signal
 HHS - Rear window defroster
 HL AV - Rear left solenoid valve pressure reduction
 HL EV - Rear left solenoid valve pressure holding
 HR AV - Rear right solenoid valve pressure reduction
 HR EV - Rear right solenoid valve pressure holding
 Ke - License plate lamp
 KP - Fuel pump group
 (L) - Low
 LP - Air pump
 L/R - Left/right
 LS - Release switch
 LWS - Steering angle sensor
 M1 - Ground 1
 M2 - Ground 2
 MBBVVL - Ground, left front brake pad wear
 MBBVVR - Ground, right front brake pad wear
 MDFHL - Ground, left rear speed sensor
 MDFHR - Ground, right rear speed sensor
 MDFVL - Ground, left front speed sensor
 MDFVR - Ground, right front speed sensor
 Mikr.+ - Microphone positive
 Mikr.- - Microphone negative
 ML - Ground (power ground°
 MMV - Solenoid valve
 MRA - Engine relay actuation
 MRU - Engine relay voltage
 MUTE - Muting
 MV+ - Solenoid valve positive
 N.C. - Not connected
 Ne - Fog lamp
 NSL - Rear fog lamp
 Not Used - Not connected
 P - Parking lamp
 R1-LED - LED display, rear window defroster switch
 R1S - Control signal, rear window defroster switch
 Rue. - Backup lamp
 S1 - Brake assist release switch, switch position 1
 S2 - Brake assist release switch, switch position 2
 SB - Accelerate (cruise control)
 SBS - Side airbag sensor
 Sig. Diag. - Diagnose Signal
 SN1 - Lock switch 1
 SN2 - Lock switch 2
 SP1M - Specified value potentiometer 1 ground


SP1S - Specified value potentiometer 1 signal
SP2M - Specified value potentiometer 2 ground
SP2S - Specified value potentiometer 2 signal
STATUS - Speed sensor output, status
SV - Decelerate (cruise control)
TK - Door contact
UB - Voltage, operation
UG - Unfused
UMRFP - Return flow pump monitor
USP1 - Voltage supply specified value potentiometer 1
USP2 - Voltage supply specified value potentiometer 2
USV - Switchover solenoid valve
VL AV - Front left solenoid valve pressure reduction
VL EV - Front left solenoid valve pressure holding
VR AV - Front right solenoid valve pressure reduction
VR EV - Front right solenoid valve pressure holding
W/S - Program selection (winter/summer)
W0 - Selector lever position code 0
W1 - Selector lever position code 1
W2 - Selector lever position code 2
W3 - Selector lever position code 3

8. Carsoft[®]™ Ultimate Home BMW Start

Click the **'Launch Carsoft'** Icon to start the software.



Click the **'BMW Ultimate'** or **'MINI Ultimate Home'** button




And the appropriate program will start.



After this you select the car type. (For Example [5 Series](#))



After the car type, you select the specific model (For Example [E60 5 series Diesel Till 2006](#))



Now you can make a selection between:



A: Total Diagnosis: Click [‘Total Diagnosis’](#)

B: Single Diagnosis: Click [‘Single Diagnosis’](#)

A: Total Diagnosis:

The 'Total Diagnosis' gives you an overview of the control units which are build in into the car. It also gives you an overview of the status of each control unit.

To start the Total Diagnosis: Click the 'Start' button.



Possibility 1: Status: OK



No actual or stored errors stored in the control unit.

Possibility 2: Status: Read the error memory!



Errors stored in the error memory.
The error memory can be read by performing a single diagnosis from the control unit.
To go to the single diagnosis, click the button at to the left side.

Possibility 3: Status: Module does not respond



Verify if the control unit is build in into the car. If so, verify the cable connection to the computer and car. Also check if the battery voltage of the car is sufficient. (>12V)

B: Single Diagnosis:


The 'Single Diagnosis' are giving you detailed information about the control units and the status of the control unit.

The screenshot displays the 'Carsoft Ultimate Home' software interface. On the left, there is a vertical banner with the 'CARSOFT BMW' logo and an image of a BMW car. The main area contains a list of single diagnosis tests, each with a button, a status indicator, and a set of three status lights (green, red, and grey).

| Control Unit | Status | Green Light | Red Light | Grey Light |
|-----------------------|------------------------|-------------|-----------|------------|
| DDE Single Diagnosis | OK | On | Off | Off |
| KI Single Diagnosis | Read the error memory! | Off | On | Off |
| SIM Single Diagnosis | OK | On | Off | Off |
| SBSL Single Diagnosis | OK | On | Off | Off |
| SBSR Single Diagnosis | OK | On | Off | Off |
| SFZ Single Diagnosis | Read the error memory! | Off | On | Off |
| STVL Single Diagnosis | OK | On | Off | Off |
| STVR Single Diagnosis | OK | On | Off | Off |
| SZM Single Diagnosis | OK | On | Off | Off |

At the bottom of the interface, there is a navigation bar with icons for 'Back', 'Main', 'Start', and 'Print', and a status bar showing the date '8/22/2008', time '3:04 PM', and the vehicle model 'BMW Vehicles\ 5 Series\ E60 5 Series DIESEL TILL 2006\ Quick Test'. There are also 'Help' and 'Exit' buttons.

Carsoft Ultimate Home




The control units are divided in the following menus:

1. ► Driveline
2. ► Chassis Systems
3. ► Body
4. ► Information and Communication
5. ► Air-conditioning

In these menus, depending to the selected car, car-type and control unit, multiple functions are possible:

Example ['Drive Line'](#)



Example ['DDE Control Unit'](#)



1. ► Read/Erase Fault Codes
2. ► Live Data
3. ► Component Info
4. ► Component Tests
5. ► Component Activations
6. ► Adaptation Functions
7. ► Etc. ...

Single Diagnosis Tests Results:

Carsoft Ultimate Home

Status Report :

Error

ECU Info :

| | |
|-------------------|----------|
| Part Number | 6767237 |
| Supplier | Bosch |
| Hardware No | 18 |
| Diagnostic Index | 1568 |
| Coding Index | 2 |
| Production Date | 31.7.03 |
| Catalog | 0.11.137 |
| Function Software | 5.4.66 |

Date: 11/10/2008 11:03:44

ECU Information:

Part Number: 6767237
 Supplier: Bosch
 Hardware No: 18
 Diagnostic Index: 1568
 Coding Index: 2
 Production Date: 31.7.03
 Catalog: 0.11.137
 Function Software: 5.4.66
 Operating Software: 0.0.0
 Variant Index: 17739

Status: ERROR-> Read the error memory...

Fault Code: F5F56
 5F56 Car Access System: internal

Fault Code: F5F14
 5F14 Brake block wear front axelle : not plausible

Fault Code: F5EBA
 E5BA Steering angle sensor not plausible

Buttons: Back, Main, Print, Save, Scan, Erase Codes, CJS, No Com., Help, Exit

11/10/2008 11:04 Passenger Vehicles 5 Series & Quick Test! ABS(ASC) Error Codes!

Possibility 1 ▶ Status: OK

Status Report :

OK

No actual or stored errors stored in the specific control unit.

Possibility 2 ▶ Status: Error

Status Report :

Error

Errors stored in the error memory.

Possibility 3 ▶ Status: No Communication

Status Report :

No Communication

Verify if the specific control unit is build in into the car. Otherwise verify the cable connection to the computer and to the car. Also verify the battery power of the vehicle.

Control Ulormation:

Used Buttons



Back ► To return to the previous screen



Main ► To return to the Main Menu



Start ► To start the Quick Test



Scan ► To start scanning the error memory



Erase Codes ► To erase the error codes



Manual ► User Manual



Save ► To save the data to disk



Print ► To print the data on paper



Exit ► To exit the program

Used Abbreviations

| | |
|---|--|
| AB - Airbag | CANH-Bus - CAN bus, High |
| ABL - Brake system warning Lamp (2 color) | CANL-Bus - CAN bus, Low |
| ABS - Anti-lock Braking System | CANP - fuel tank ventilation valve |
| AC - Air Conditioning | CAS - Car Access System |
| ACC - Active Cruise Control | CBC - Corner Braking Control |
| ACS - Active Comfort Seats | CBS - Condition Based Service |
| ADB(X) - Automatic Differential Braking | CCM - Check Control Module |
| ADS - Engine intake air control | CD - Control Display |
| ADV - Windshield wiper pressure control | CDC - Compact Disk Changer |
| AEGS - Automatic Electronic Gearbox Control (also EGS) | CDS - CD player |
| AFM - Air Flow Meter | CIM - Chassis Integration Module |
| AGD - Suction silencer | CO - Carbon monoxide |
| AGR - Emission reduction | COMBI – Electronic Instrument Cluster |
| AGS - Adaptive transmission control | CON - Controller |
| AG - Automatic Gearbox (transmission) | CVM - Convertible top Module |
| AHK - Active rear-axle Kinematics | CVT - Constantly Variable Transmission |
| AHK - Trailer hitch | CW - Drag coefficient |
| AHM - Trailer Module (not for US models) | CWP - Cold Weather Package |
| AHPS - Advanced HPS | D1 - Xenon light/ gas discharge |
| AIC - Automatic Interval Control (rain sensor) | D-Bus - Diagnosis bus (same as TXD) |
| AKF - Activated carbon canister | DBC - Dynamic Brake Control |
| AKS - Active head restraint | DBS - Dynamic Braking System |
| AKS - Pressure regulating device | DCS - Dealer Communication System |
| ALC - Automatic Light Control | DE – Diagnostic Unit |
| ALR - Automatic Lamp Range Adjustment | DD - Dynamic motor Drive |
| AMM - Air Mass Meter | DDE - Digital Diesel Electronics |
| AMP - Radio system Amplifier | DIN - German industrial standards |
| ARI - Car radio information system | DIS - Diagnosis and Information System |
| ARS - Active Roll Stabilization | DISA - Differential air intake control |
| ASC - All Season traction | DIVA - Continuously variable length intake runners |
| ASC-EZA - ASC w/ engine timing and injection intervention | DK - Throttle housing/valve |
| ASC+T - ASC+ Traction control | DKB - Throttle w/ brake intervention |
| ASK - Audio System controller | DKE – Throttle Increase |
| ASR - Self starter block relay | DKI - Throttle position |
| AT - Remanufactured part | DKR - Throttle reduction |
| AT - Antenna | DKT - Throttle position signal |
| ATF - Automatic Transmission Fluid | DKV - Preset throttle position value |
| ATL - Exhaust gas turbo charger | DME - Digital Motor Electronics |
| AUC - Automatic air recirculation | DM-TL - Diagnostic Module Tank Leakage |
| AUT - Automatic transmission | DOHC - Double Over Head Camshafts |
| AVT - Antenna amplifier Tuner | DS - Gasket set |
| AZD - Tightening torque specifications | DSC - Dynamic Stability Control |
| A/D – Analogue/Digital | DSP - Digital Sound Processing |
| B - Benzine (gasoline) | DTC - Diagnostic Trouble Code (SAE) |
| BAT - Battery | DTC - Dynamic Traction Control |
| BC - Board Computer | DWA - Theft deterrent system |
| BC1 - Body Controller 1 | DWS - Tire pressure Warning System |
| BL - Brake Light | DZM - revolution counter |
| BLS - Brake Light Switch | E - “in” (Ein) |
| Bluetooth - A wireless interconnection technology | EBV - Electronic Brake force proportioning |
| BMBT - Board Monitor | ECE - European market version |
| BS - Block diagram | ECM - Engine Control Module |
| BST - Battery Safety Terminal | ECU - Electronic Control Unit |
| BVA - Brake pad wear indicator | EDC - Electronic Damper Control |
| BZM - Centre console control centre | EDR - Electronic throttle control |
| BZMF - Centre console control centre, rear | E-KAT - Electrically heated catalytic converter |
| CAN – Controller Area Network | EZA - See ASC-EZA |
| CAN-Bus - Controller Area Network (bus) | ECM - Engine Control Module |
| | ECO - Controller for I-Drive system |
| | EDC - Electronic Dampening Control |

EDC-K - Electronic Dampening Control - Continuous
EDK - Electronic throttle valve
EDS - Pressure regulator
EFH - Electric window lifter
EGS - Electronic transmission control
EH - Electronic-Hydraulic
EHC - Electronic Height Control
EKM - Electronic body Module
EKP - Electric fuel Pump
ELV - Electronic steering lock
EM - Electro-Mechanical
EMF - Electro-Mechanical parking brake
EML - Electronic Motor Load regulation
EMV - Electro-Magnetic sensitivity
EO - Component location
EPC - Electronic Parts Catalogue
EPROM - Erasable/ Programmable chip Memory
ETK - Electronic parts catalogue
ETM - Electrical Troubleshooting Manual
ESS - Electronic anti-theft device
EV - Injection Valve
EWS - Electronic drive-away protection
FB - Function description
FBC - Fading Brake Control
FBD - Remote control services
FBZV - Radio frequency locking system
FGR – Vehicle Speed Control (Cruise Control)
FH - Window lifter
FHK - Rear Heater/ air conditioner
FLC - Automatic Light Control
FRU - Flat Rate Unit
FS – Crash Sensor
FZV - Central lock receiver
GAL - Speed dependent sound volume
GM - General Module
GMR - Yaw moment control
GPS - Global Positioning System
GRII - Cruise Control
GRS - Rotation Rate Sensor
GS – Belt Tensioned
GWK - torque converter lock-up control
H - “rear”
H2 - Xenon headlights
HA - Rear Axle
HC – Hydro Carbon
HD - Heavy Duty
HDC - Hill Decent Control
HFM - Hot Film air mass Meter
HG - Manual Gearbox (transmission)
HKL - Hydraulic trunk lid Lift
HLM – Hot Wire Air Mass Meter
HPS - Head Protection System
HR - Heater control (from ETK)
HVA - Hydraulic Valve Adjuster
Hz – Hertz (Cycle)
I-Bus - Information bus
IB - Interior lighting control signal
IHKA - Automatic Heating and A/C
IHKAF - IHKA w/ micro filter
IHKR - Regulated Heating and A/C
IHKRF - IHKR w/ micro filter
IHKS - Standard Heating and A/C
IHPD - Internal High Pressure Deformation
IHR - Integrated Heater control
IKE - Instrument cluster Electronics
ILH - Interior Lighting, rear
ILV - Interior Lighting, front
IMS - Instant Mobility System
IR – Infrared
IRS – Infrared Locking System
ISC – Idle Speed Control
ISIS - Intelligent Safety Integration System
ISN - Individual Serial Number
ISOFIX - Standardized mounts for child restraints
ITS - Head airbag assembly/ Inflatable Tubular Structure
IVM - Integrated power supply Module
K-Bus - Body bus
KAT - Catalytic converter
KATON - Converter creating (signal)
KD - Kick-Down
KHI - Interface for headphones
KL - Terminal designation
KL15 - Run bus (ignition switch run position)
KL30 - Battery bus (hot at all times)
KL31 - Ground bus (chassis ground)
KL50 - Start bus (ignition start position)
KLR - Accessory bus
KO - Compressor “on” signal
KOMBI - Instrument cluster
KOREL - Compressor relay signal
KR – Contact Ring
KSK - Knock Sensor
KVA - Fuel consumption signal/value
KW - Crankshaft
KW - Kilowatt
LCM - Lamp Check Module
LDP - Leak Diagnosis Pump
LEV - Low Emissions Vehicle
LEW - Lateral acceleration sensor
LHD - Left-Hand Drive
LKM - Lamp control Module
LL - Closed throttle
LM - Light Module
LMM - Air flow meter/sensor
LMR - Light alloy wheel
LRA - Vertical headlight aiming
LSM - Steering column memory
LSZ - Lamp switching center
LVA - Air supply system (for EHC system)
LWR - Vertical headlight aim control
LWS-5 - Steering angle sensor
M-Bus - IHKA/IHKR stepper motor bus
MAL - Centre armrest
MBC - Maximum Brake Control
MDK - Motorized throttle valve/system
MFL - Multi-Function steering wheel
MFC - Multi-Function Controller
MFU - Multi-Function Clock
MID - Multi-Information Display
MIL - Malfunction Indicator Lamp (SAE), “check engine” Lamp
MIR - Multi-Information Radio
MMC - Multimedia Changer
MOST-Bus - Media Oriented System Transport bus
MRS - Multiple Restraint System

MSR - engine drag torque Regulation
 MV - Magnetic Valve (solenoid Valve)
 n-ab - Rotational speed, transmission (rpm)
 n-mot - Rotational speed, engine (rpm)
 NAVI - Navigation module
 NG - New Generation
 NG - Tilt sensor
 NOX - Nitrogen Oxides/ exhaust gas recirculation
 NSD - Rear muffler
 NSL - Rear fog Lamp
 NSW - Fog lamp
 NTC - Negative Temperature Coefficient
 NW - Camshaft
 OBC - On-Board Computer
 OBD - On-Board Diagnosis (SAE)
 P/N - Park/Neutral position
 P-Bus - Periphery bus
 PB - Pin assignments
 PBS - Parts Bulletin System
 PDC - Park Distance Control
 PGS - Passive Go System
 PM - Power Module
 PP - Impact Pad
 PTC - Positive Temperature Coefficient
 RLS - Rain-Light Sensor
 PWG - Pedal position sensor/ potentiometer
 RA - Repair instructions
 RAM - Random Access Memory
 RAL - Aluminium wheels
 RAL - Standard colour
 RDC - Tire pressure Control
 RDS - Radio Data-broadcast System
 RDW - Tire pressure Warning
 RHD - Right-Hand Drive
 RM - Relay Module
 ROZ - Research Octane rating/ fuel grade
 RPA - Tire puncture warning
 RPS - Rollover Protection System
 RS - Repair kit
 RSW - Back-up lamp
 RXD - Wake-up Diagnosis line
 RZV - Direct stationary ignition
 SASL - Satellite, A-pillar left
 SASR - Satellite, A-pillar right
 SAV - Sport ACTIVITY Vehicle
 SB - Fuse assignments
 SBE - Seat occupancy detector/sensor
 SBFH - Seat module, passenger-side rear
 SBSL - Satellite, B-pillar left
 SBSR - Satellite, B-pillar right
 SBT - Tech reference information
 SCA - Soft Close Automatic/Actuator
 SD - Sliding roof
 SD - Silencer/ muffler
 SE - Special Equipment
 SES - voice recognition System
 SFAH - Seat module, driver's side rear
 SFZ - Satellite, vehicle center
 SG - Control unit
 SGS - Seat integrated belt System
 SHD - Sliding/ lifting roof
 SHD - Sunroof module (also SHDM)
 SI - Service Information
 SIA - Service Interval system (ver. I, II, III, IV, etc.)
 SII - Service Interval Indicator
 SIM - Safety Information Module
 SINE - Siren/tilt sensor
 SKD - Steel sliding roof
 SKHD - Steel sliding/ lifting roof
 SM - Seat Module
 SM/SPM - Seat/Mirror Memory
 SMBF - Seat Module, passenger side
 SMFA - Seat Module, driver's side
 SMG - Sequential Manual Gearbox
 SP - Schematic
 SRA - headlight/fog light cleaning
 SRS - Supplementary Restraint System
 SSD - Steel sliding roof
 SSH - Seat Satellite, rear seat
 ST - connector views
 Steptronic - transmission shift control
 STVL - Satellite, left front door
 STVR - Satellite, right front door
 SVS - Speech processing System
 SWR - Headlamp cleaning system
 SWZ - Special tool listings
 SZL - Switch centre, steering column
 SZM - Central switch centre Module
 TAGE - Door handle Electronics
 TCM - Transmission Control Module
 TD - Engine speed signal (ignition pulse)
 TD - Technical Data (in TIS)
 TE - Fuel evaporation control
 TEL - Telephone control unit
 TEV - Evaporative purge control
 THZ - Tandem master cylinder
 ti - Injector "on" Time (duration)
 TIS - Technical Information System
 TL - Part throttle / load signal
 TLEV - Transitional Low Emission Vehicle
 TMBFT - Door Module, passenger side
 TMBFTH - Door Module, passenger side rear
 TMFAT - Door Module, driver's side
 TMFATH - Door Module, driver's side rear
 TP - Tandem Pump
 TPS - Throttle Position Switch/Sensor
 TR - Engine speed signal (rpm)
 TR - Transistor
 TRG - fuel level sensor
 TRI - Technical Reference Information (also SBT)
 TRS - Battery isolation Switch
 TSD - Torsion vibration dampener
 TSB - Technical Service Bulletin
 TSH - Door lock Heating
 TSZI - Transistorized coil Ignition system
 TU - Technical Update
 TXD - Transmitting Diagnosis line
 U-batt - Battery voltage
 U-vers - Supply voltage
 UERSS - Rollover bar
 URS - Rollover protection System
 USIS - Ultrasonic passenger compartment Sensor
 V - "front"
 V - Vehicle road speed
 VA - Front Axle
 VAT - Front axle support
 VANOS - Variable camshaft timing
 VEP - Distributor-type injection Pup

VID - Video module
VL - Full load (wide open throttle)
WBG – Hazard warning switch
WIM - Wiper control Module
WK - Torque converter lock-up clutch
WSS – Wind Shield
ZAB - Ignition fade-out (reduction)
ZAE - Central Airbag Electronics
ZAS - Ignition starter switch
ZGM - Central Gateway Module
ZK - Cylinder head
ZKE - Central body Electronics
ZKH - Cylinder head cover
ZMS - Dual-Mass flywheel
ZV - Central locking system
ZS - Central lock
ZSD - Center muffler
ZV - Central locking system
ZVM - Central locking Module
ZWD - Idle control valve

APPENDIX A: No Communication

Possible causes in case that the module is not responding:

- ▶ **The Control Unit Not Build In (The vehicle is not equipped with this control unit)**
- ▶ **Control Unit Power Supply:**
 - **Verify for: Low battery voltage**
 - **Verify if the diagnostic cable is properly connected to the diagnostic socket and to the computer port.**
 - **Bad power or ground circuits on the diagnostic socket**
- ▶ **Wrong Communication port setting from the computer**

APPENDIX B: Contact Info:

► Website:

www.carsoftinternational.com

The advertisement for Carsoft Ultimate features a blue background with a grid pattern. At the top right, it says "Carsoft International" with a small logo and "OnBoard Diagnostic Systems" below it. The main title "Carsoft Ultimate" is in large white letters, with the tagline "Great Value - Fantastic Coverage" underneath. The text "Mercedes" is written vertically on the left, "BMW" on the right, and "MINI" at the bottom right. The word "Sprinter" is written below a silver van. The phrase "For All" is centered in the background. Three vehicles are shown: a silver SUV (Mercedes), a silver sedan (BMW), and a silver MINI car. At the bottom, there are two buttons: "Professional Edition" and "Home Edition".

► Email:

bmwhome@carsoftsales.com

► Phone:

+32 19 54 54 29

► ...or contact your local Carsoft distributor

APPENDIX C: Oxford RS 232 - PCMCIA Card



A) Installing the controller card into the notebook

1. Insert the controller card into an empty PCMCIA slot. As the card supports Hot Plug function, it could be inserted into the PCMCIA slot while notebook is in power on or power off condition.
2. When the card is detected, the OS will ask for the software driver.

B) Installing Windows driver for the controller card

1. Once Windows is running, a new controller card is detected.
2. Insert the Drivers & Utility Cd into the CD-ROM, assume drive D
3. When the system ask for the driver for CF Gen, choose "Install from a list or specific location (Advanced)"
4. Choose "Don't search. I will choose the driver to install"
5. Choose "Ports (COM & LPT)"
6. Click on "Have Disk"
- 7 Browse to the following directory on the CD Driver: D:\Oxford\OX95x\Windows
8. Choose "OxSER.INF"
9. Select "PCcard OX16CF950"
10. Follow the on screen instructions until the driver is totally installed

C) Checking the status of the installed driver

1. Right click on the icon of My Computer and choose Properties
2. Choose Device Manager
4. Let click on the "+" sign of the Ports (COM & LPT)
4. The following devices should be shown PCCard OX16CF950
5. Right click on the device above and choose Properties
6. Check the Device Status in the General window. The following should be shown:
This Device is Working Properly

Changing COM Port number:

Some serial devices need a special COM port in order to work. If your serial device works properly, do not change this setting.

1. From the Device manager Window double click Ports (COM & LPT), then double click the Profilic USB-to Serial Comm Port ... you want to change.
2. Click port Settings tab and click Advanced ...
3. Click the down arrow that is next to the COM Port Number box, select a COM port that us not in use, then click OK.
4. Click OK, then close Device Manager to save the changes.

APPENDIX D: APIOTEK RS232 - Express Card



Windows XP/Windows 2000 Installation

1. Don't insert the Express Card into the Express Card Slot.
2. Insert the CD into the CD-ROM Drive.
3. At the Windows desktop click Start, then RUN.
4. Type D:\EC-0008(Serial port)\WIN98SE&ME&2K&2003\Setup.exe
5. Follow the on-screen instructions to complete the installation.
6. Insert the Serial Express Card into the Express card slot.
7. Open 'Device Manager' under System Properties and check if there is the device you install under "Profilic USB-to-Serial-Comm Port ..."
8. Now the Serial Express Card is ready to use.

Windows Vista Installation

1. Don't insert the Express Card into the Express Card Slot.
2. Insert the CD into the CD-ROM Drive.
3. At the Windows desktop click Start, then RUN.
4. Type D:\EC-0008(Serial port)\VISTA\Setup.exe
5. Follow the on-screen instructions to complete the installation.
6. Insert the Serial Express Card into the Express card slot.
7. Open 'Device Manager' under System Properties and check if there is the device you install under "Profilic USB-to-Serial-Comm Port ..."
8. Now the Serial Express Card is ready to use.

Changing COM Port number:

Some serial devices need a special COM port in order to work. If your serial device works properly, do not change this setting.

1. From the Device manager Window double click Ports (COM & LPT), and then double click the Profilic USB-to Serial Com Port ... you want to change.
2. Click port Settings tab and click Advanced ...
3. Click the down arrow that is next to the COM Port Number box, select a COM port that us not in use, then click OK.
4. Click OK and then close Device Manager to save the changes.