

NEW VOLTAGE CODES



<http://stores.ebay.com/UsefulCDs>

NEW VOLTAGE CODES

OLD

4.0 BGE-1R/26100F

NEW

4.0 BGE-FA/26100F

	Starting/Portability Codes	Replaces
A	Portable - Manual Start - Non Remote	P
B	Portable - Electric Start - Non Remote	
C	Portable - Electric Start - Remote	
D	Stationary - Manual Start - Non Remote	M
E	Stationary - Electric Start - Non Remote	E
F	Stationary - Electric Start - Remote	R

60 HZ	Voltage/Frequency Codes		
		50 HZ	
A	120 Volt, 1 Phase, 2 Wire	M	110/220 Volt, 1 Phase, 4W
B	120/240 Volt, 1 Phase, 3W	N	120/240 Volt, 1 Phase, 3W
C	120/208 Volt, 3 Phase, 3W	P	120/240 Volt, 1 Phase, 4W
D	120/240 Volt, 3 Phase, 4W	S	120/240 Volt, 3 Phase, 4W
E	240/480 Volt, 3 Phase, 4W	T	220/380 Volt, 3 Phase, 4W
F	220/380 Volt, 3 Phase, 4W	U	240 Volt, 1 Phase, 2W
G	277/480 Volt, 3 Phase, 4W	V	Not Assigned
H	347/600 Volt, 3 Phase, 4W	W	Not Assigned
J	120/240 Volt, 1 Phase, 4W	X	Not Assigned
K	416/440, 480 Volt, 3 Phase, 4W	Y	380, 400, 416 Volt, 3 Phase, 4W
L	Reconnectible	Z	Reconnectible
R - Special - See Prod. Order			

Voltage Codes - A.C.

<u>New</u>	<u>Voltage</u>		<u>Old</u>
A	120V 1Ø 2 Wire	60 Hz	1
B	120/240V 1Ø 3 Wire	60 Hz	3
C	120/208V 3Ø 3 Wire	60 Hz	4
D	120/240V 3Ø 4 Wire	60 Hz	5D
E	240/480V 3Ø 4 Wire	60 Hz	6D
F	220/380V 3Ø 4 Wire	60 Hz	7
G	277/480V 3Ø 4 Wire	60 Hz	4X
H	347/600V 3Ø 4 Wire	60 Hz	9X
J	120/240V 1Ø 4 Wire	60 Hz	3C
K	416/440, 480V 3Ø 4 Wire	60 Hz	New (Newage)
L	Reconnectible	60 Hz	39, 25, 15, 17, 18, 47, 39
M	110/220V 1Ø 4 Wire	50 Hz	53B
N	120/240V 1Ø 3 Wire	50 Hz	53
P	120/240V 1Ø 4 Wire	50 Hz	53C
R	Special	All Hz	3B, 3A, 5, 6, 8, 9, 1X, 2X, 3X, 5X, 6X, 7X, 8X, 99, 14, 16, 31, 32, 33, 35, 38, 53A, 519, 520, 521, 522, 523, 524, 536, 37, 215, 206, 212, 224, 225, 226, 228, 232, 210, 114, 115, 125, 123, 128, 136, 144, 150, 330, 331, 332, 341, 343, 381
S	120/240V 3Ø 4 Wire	50 Hz	55D
T	220/380V 3Ø 4 Wire	50 Hz	57
U	240V 1Ø 2 Wire	50 Hz	52
V	Future		
W	Future		
X	Future		
Y	380, 400, 416V 3Ø 4 Wire	50 Hz	525
Z	Reconnectible	50 Hz	515, 517, 518, 547, 539
	Obsoleted		2, 3U, 36, U

Revised 8/94

SERIAL NUMBER MICROFICHE

PURCHASE: Order by part number on your regular parts orders.

932-0243 Serial numbers from 1940 – 1972

932-0234 Serial numbers from 1973 – 1982

932-0235 Serial numbers from 1983 – 1996

USE: Each microfiche card indicates on the top band the beginning serial number. Each serial number microfiche card gives the following information:

